

## **Toyota Prius 2004-2009**

Step-by-Step Hybrid Battery Removal and Installation Instructions

Video demonstration is available at our website: www.BestHybridBatteries.com

These instructions are provided only as a guide and it is your responsibility to use the proper techniques and safety measures. Best Hybrid Batteries assumes no responsibility for any damage to person or property from the misuse of our products or from failure to use the proper techniques and safety measures. Do not attempt this work if you are not qualified and competent. Use these instructions at your own risk.

Steps	Tool	Description	Photo
	You will need the following tools:	8mm 10mm 12mm 14mm Fabric pin puller	
Step 1	14 mm	Fold down back seats, peal back velcro covers, loosen all 4 bolts (14mm) with the manual socket wrench, then remove the loosened bolts with the battery operated tool	

Step 2	Hands	Open hatch, remove retracting cover, storage cover, center storage compartment, left storage compartment and cover, and 12V battery cover on right side.	
Step 3	Red handled fabric pin puller	Loosen fabric pins as shown (5 total)	
Step 4	10mm	Loosen all 8 of the 10mm bolts going clockwise around the hatch area	
Step 5	10mm	Remove the 10mm nut connecting battery cable to car	

Step 6	Hands	Remove the orange main disconnect plug	
Step 7	Hands	Pop off the battery cover, the center back cover, and the left and right fabric pieces. Loosen white plastic light clip behind left fabric piece	
Step 8	Hands	Remove the black plastic cooling fan duct (upper piece only)	

Step 9	12mm	Take out all 17 of the 12 mm bolts holding down the battery	
Step 10	10mm	Take off the 5 nuts and bolts securing the left side battery cover	
Step 11	8mm	Take off the 2 nuts securing the orange battery leads, tuck behind seat bracket	
Step 12	Hands	Disconnect all three plastic cable clips	

